

Abbreviated Operating Instructions for the Titan™ Lock on Your Safe

Complete, official instructions for this product are contained in Sargent & Greenleaf document 630-804, available at www.sargentandgreenleaf.com.

Code Restrictions: Personal data that can be related to a code holder, such as a birth date, street number, or phone number, should not be used in creating a lock code. Avoid codes that can be easily guessed. After the lock is changed to a new code, the lock function must be checked by locking and unlocking it several times with the container door open. Make sure it functions correctly before closing the door.

Opening the Lock with No Time Delay

To open the lock, enter a valid lock code followed by #. The lock will open.

Opening the Lock if a Time Delay is Set

To open the lock, enter a valid lock code and #. The lock will beep 3 times. During the time delay period, the lock will beep once every 10 seconds. At the end of the time delay, the lock will beep 10 times rapidly. Enter a valid lock code and # to open the lock. The second code may be the same as the code used to start the time delay, or it may be a different valid lock code.

Creating a Supervisor or User Code

7 4 * MASTER CODE OR SUPERVISOR CODE # () PIN POSITION FOR CODE TO BE CHANGED OR ADDED # () NEW CODE # () NEW CODE # ()

Note: The Supervisor Code cannot change the Master Code.

PIN Positions: 1 Supervisor Code
 2 – 9 User

Code Holder Changes His Own Code

3 3 * EXISTING CODE # () NEW CODE # () NEW CODE # ()

Deleting a Code

7 4 * MASTER CODE OR SUPERVISOR CODE # () PIN POSITION # () # () # ()

Notes: The Master Code cannot be deleted. The Supervisor Code cannot be used to delete itself. A time delay override code can only be deleted by the Master Code holder and only from within an opening window period following a time delay period.

PIN Positions: 1 Supervisor Code
 2 – 9 User Codes

Set Keypad Beeper Volume

7 8 * MASTER CODE # () 0 # 0 # for "OFF" OR 1 # 1 # for "LOW" OR 2 # 2 # for "HIGH" ()

Setting, Changing, or Deleting a Time Delay

7 4 * MASTER CODE # () 00 # LENGTH OF DESIRED TIME DELAY # () LENGTH OF DESIRED TIME DELAY # ()

Note: The time delay period can be set anywhere from 1 to 99 minutes. An existing time delay can only be changed within an opening window period following a time delay period. To delete a time delay, enter the length of desired time delay as zero.

Using the Management Reset Code

6 7 * Management Reset Code # () NEW 6-DIGIT MASTER CODE # () NEW 6-DIGIT MASTER CODE # ()

Note: All codes are automatically deleted when the Management Reset Code is used. Not affected are the time delay period (if one was set), opening window period (if a time delay was set), duress function, or lock access mode.